

A leader doesn't follow steps, **he marks the way.**



## WHAT'S A CONFI-BICI?

The lane separators are an easy, simple, and profitable way to divide bike lanes on roads. Thus, more safe spaces for cyclists are created.




The lane channelizers help cyclists move around the bike lane, increase their safety, and signal vehicle drivers of the separation. They are visible day and night due to their reflective stripes on the sides and ends that reflect with car lights.

On narrow roads, you can use the Confi-Bici 25 which is the same model but with just 9.75 in. width.


## Features

- "Confi-Bici 40" Lane separator.
- Modern, powerful, and cutting-edge product.
- Made of polyethylene.
- It has UV protection.
- Molded in one piece with the extrusion molding process. Color: Yellow.
- It has resistance to humidity, oil, and temperature changes.
- The rounded edges provide maximum security and don't harm cyclists.
- The ramp with anti-skid ribs on the side prevents cyclists from falling if they get on the lane separator by accident.
- The reflectives have a high relief design that protects the reflective layer on both ends and provides great visibility to the drivers.
- The eight reflectives on the sides are angled which allows greater visibility to the drivers.
- It has the option of adding your logo.
- The seven anchorage ovals are designed to absorb the expansion of the lane separator when the temperature rises during the day and at night with the contraction of plastic at a lower temperature.
- Easy to install: It anchors to the floor with seven nails of 1/2" x 10" and epoxy glue (not included).

PATENT PENDING



Volumes, dimensions, and other measures are nominal and may vary by approximately 2 %.



## Installation

### Measures

**Total**


Length: 5 ft 10 in.  
 Width: 15.6 in.  
 Height: 5 in.

**Reflectives**

Amber, white, and red.

Mark the boreholes using the Confi-Bici as a template.  
 Bore into the holes with a drill and a 1/2" drill bit at a depth of 7".  
 Fill with a little epoxy glue.  
 Put the Confi-Bici and carefully pound the nails on each hole.  
 Make sure to put the nails in the center of the oval so that when there's expansion or contraction by temperature the nails don't get loose.

It anchors to the floor with four nails of 1/2" x 10" and epoxy glue (not included).



Installation with epoxy glue

Steel nail  
 (1/2" x 9.75 in.)